




PILE SPACING

16K Thru 27K

6 PILE



*Important: Vessel's weight must be centered on the boat lift.
Verify proper balance by checking tension at each lift cable.*

www.FixMarineSupply.com
1-866-998-3625