




# PILE SPACING

## ***30K, 35K, 40K***

## ***8 PILE***



*Important: Vessel's weight must be centered on the boat lift.  
Verify proper balance by checking tension at each lift cable.*

[www.FixMarineSupply.com](http://www.FixMarineSupply.com)  
**1-866-998-3625**