




PILE SPACING

10K & 13K



*Important: Vessel's weight must be centered on the boat lift.
Verify proper balance by checking tension at each lift cable.*

www.FixMarineSupply.com
1-866-998-3625